


Efka euramot

CONTROL

AB60D1472



LIST OF PARAMETERS

**CONNECTION DIAGRAM
TIMING DIAGRAMS**

No. 402290

English

Efka
FRANKL & KIRCHNER
GMBH & CO KG

Efka
EFKA OF AMERICA INC.

Efka
EFKA ELECTRONIC MOTORS
SINGAPORE PTE. LTD.

| CONTENTS | Page |
|---|-------------|
| 1 Table of Adapter Cords | 5 |
| 2 Putting into Service | 6 |
| 3 Operating Elements and Connectors | 7 |
| 3.1 Position of the Operating Elements, Displays and Connectors | 7 |
| 3.2 Connection Diagram | 8 |
| 4 Connection Scheme of an SM210A Stepping Motor Control | 12 |
| 4.1 Adapter Cords | 13 |
| 5 Timing Diagrams | 26 |
| 6 List of Parameters | 58 |
| 6.1 Preset Values Depending on Mode | 58 |
| 6.2 Operator Level | 60 |
| 6.3 Technician Level | 61 |
| 6.4 Supplier Level | 65 |
| 7 Error Displays | 69 |

1 Table of Adapter Cords



ATTENTION!

Before switching functional sequences, detach cables from the inputs and outputs! Please ensure that the machine installed provides the functional sequence to be set! **Then proceed with the setting using parameter 290!**

| Setting the functional sequence using parameter 290 | | | | | | | | | | |
|---|--|---------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Mode | Designation | Adapter | Outputs | | | | | Inputs | | |
| | Power transistors → | | FL ST2/35 | M1 ST2/37 | M2 ST2/28 | M3 ST2/27 | ML ST2/32 | in1 ST2/7 | in3 ST2/6 | in4 ST2/8 |
| 0 | Lockstitch; e. g. Brother (737-113, 737-913) | 1112814 | FL | FA1 + | FA2 | FW | - | - | NHT | - |
| | Aisin (AD3XX, AD158, 3310; EK1) | 1112815 | FL | FA1 + | FA2 | FW | - | - | NHT | - |
| | Pfäff (563, 953, 1050, 1180) | 1112841 | FL | FA1 | FA2 | FW | ML | - | - | FLEX |
| | Dürkopp Adler (210, 270) | 1112845 | FL | FA1 + | FA2 | FW | - | - | NHT | EST |
| | Lockstitch; e. g. Singer (591, 211U, 212U) | 1112824 | FL | - | FA2 | FW | - | NHT | - | - |
| 2 | Lockstitch; e. g. Singer (212 UTT) | 1112824 | FL | - | FA | FSPL | - | NHT | - | - |
| 3 | Lockstitch; e. g. Dürkopp Adler (467) | | FL | FA | FSPL | FW | ML | NHT | - | - |
| 4 | Chainstitch; Union Special (34000 and 36200 replacement for US80A) | 1112865 | FL | - | FA-V | FW | ML | LSP | LSP | ENTK |
| | (CS100 and FS100) | 1112905 | FL | - | FA-V | FW | ML | LSP | LSP | - |
| 5 | Chainstitch; parallel sequence Yamato (VC series) | 1112818 | FL | FA | - | FW | - | LSP | - | - |
| | Yamato (VG series) | 1113178 | FL | FA | - | FW | - | LSP | - | - |
| | Kansai (RX 9803) | 1113130 | FL | FA | - | FW | ML | LSP | - | - |
| | Pegasus (W500/UT) | 1112821 | FL | FA | FA | FW | - | LSP | - | - |
| | Brother (FD3-B257) | 1112822 | FL | FA | FA | FW | - | LSP | ENTK | - |
| | Global (CB2803-56) | 1112866 | FL | - | FA | FA | - | LSP | - | - |
| | Rimoldi (F27) | 1113096 | FL | FW | FAO | FAU | ML | - | - | - |
| 6 | Chainstitch; tape cutter/fast scissors | | FL | M1 | AH1 | AH2 | ML | - | - | - |
| 7 | Overlock | | FL | M1 | M2 | AH | ML | - | - | - |
| 8 | Backlatch; Pegasus | 1113234 | - | PD≤-1 | PD≥1 | - | - | LSP | N.AUTO | - |
| 9 | Backlatch; Yamato (ABT3) | 1112826 | - | PD≤-1 | PD≥1 | - | - | LSP | N.AUTO | - |
| | Backlatch; Yamato (ABT13, ABT17) | 1113205 | - | PD≤-1 | PD≥1 | - | - | LSP | N12.AU | N9.AU |
| 10 | Lockstitch; e. g. Union Special (63900AMZ replacement for US80A) | 1113199 | FL | - | FA-V | FW | ML | - | - | - |
| 11 | Reversal of motor rotation with pedal in pos.-2 | | FL | DR-UK | PD=-2 | ML | ML | N.POS | - | - |
| 12 | Reversal of motor rotation with input in3 | | FL | DR-UK | PD=0 | ML | ML | N.POS | DR-UK | - |
| 13 | Lockstitch; Pfäff (1425) | 1113072 | FL | FA | FSPL | FW | ML | NH | POS2 | DB |
| 14 | Lockstitch; e. g. Juki (5550-6) | 1112816 | FL | FA1+2 | - | FW | - | - | - | - |
| | Juki (5550-7) | 1113132 | FL | FA1+2 | FZ | FW | - | - | - | - |
| 17 | Chainstitch; Pegasus | | FL | M1 | M2 | M3 | ML | - | - | - |
| 18 | Overlock; Bottoms | | FL | M1 | AH | M3 | ML | - | - | - |
| 19 | Lockstitch; Macofrey | | FL | FA-R | FA-V | FW | ML | - | - | - |
| 20 | Lockstitch; Juki (LU1510-7) | 1113200 | FL | FA | FSPL | - | - | - | BIT0 | BIT1 |
| 22 | Lockstitch; Brother (B-891) | | FL | FA | FSPL | FW | ML | - | - | - |

Explanation of letter symbols of the previous page and chapter "Timing Diagrams"
Outputs:

| | |
|------------|--|
| FL | = Sewing foot lifting |
| FA1 | = Thread trimmer pos. 1...1A |
| FA2 | = Thread trimmer pos. 1A...2 |
| FA1+2 | = Thread trimmer pos. 1...2 |
| FSPL | = Thread tension release |
| FA-R/FA-V | = Thread trimmer backward/forward |
| ML | = Machine running |
| FW | = Thread wiper |
| AH/AH1/AH2 | = Tape cutter / Tape cutter 1/ Tape cutter 2 |
| DR-UK | = Reversal of motor rotation |
| PD=0 | = Pedal step 0 |
| PD-2 | = Pedal step -2 |
| FAO | = Needle thread trimmer |
| FAU | = Bobbin thread trimmer |
| FZ | = Thread puller |
| PD≥1 | = Pedal steps 1...12 |
| PD≤-1 | = Pedal steps -1 / -2 |

Inputs:

| | |
|--------|--------------------------------|
| NHT | = Needle up/down |
| EST | = Single stitch |
| FLEX | = External sewing foot lifting |
| N.POS | = Positioning speed |
| N.AUTO | = Automatic speed |
| N9.AU | = Automatic speed n9 |
| N12.AU | = Automatic speed n12 |
| LSP | = Machine run blockage |
| DR-UK | = Reversal of motor rotation |
| NH | = Needle up |
| POS2 | = Run to position 2 |
| DB | = Speed limitation n12 |
| ENTK | = Unlocking the chain |
| BIT0 | = Speed limitation bit 0 |
| BIT1 | = Speed limitation bit 1 |

2 Putting into Service


Before putting the control into service, the following must be ensured, checked and/or adjusted:

- **The correct installation of the drive, position transmitter and accompanying devices, if necessary**
- **The correct selection of the trimming operation using parameter 290**
- **If necessary, the correct adjustment of the direction of motor rotation using parameter 161**
- **The correct selection of functions of the keys (inputs) using parameters 240...249**
- **The correct positioning speed using parameter 110**
- **The correct maximum speed compatible with the sewing machine using parameter 111**
- **The setting of the positions**
- **The setting of the remaining relevant parameters**
- **Start sewing in order to save the set values**

See instruction manual for details!

3 Operating Elements and Connectors


3.1 Position of the Operating Elements, Displays and Connectors



| | |
|------------------------|---|
| S1 P key | Call or exit programming mode |
| S2 E key | Softstart on / off |
| S3 + key | Enter key for modifications in the programming mode |
| S4 – key | Thread trimmer/thread wiper on / off |
| S5 >> key | Increase of the value indicated in the programming mode |
| | Automatic sewing foot lift at stop in the seam On/Off |
| | Automatic sewing foot lift after trimming On/Off |
| | Decrease of the value indicated in the programming mode |
| | Basic position 1 or 2 |
| | Shift key in the programming mode |
| Display | 3 digits |
| B1 | Connection of position transmitter |
| B2 | Connection of commutation transmitter for d.c. motor |
| B4 | Inputs of keys or switches |
| B18 | Connection of light barrier module or stepping motor control |
| B80 | Connection of actuator |
| ST2 | Inputs and outputs for solenoids, solenoid valves, displays, keys or switches |

3.2 Connection Diagram


Inputs switched to 0V



ATTENTION!
When connecting the outputs, ensure that a total power of 70VA constant load will not be exceeded!


- | | | | | | |
|---------|--|----|-----------------------|------|----------------------|
| in1 | - Input 1 | M1 | - Output 1 | POS1 | - Position 1 |
| in3 | - Input 3 | M2 | - Output 2 | POS2 | - Position 2 |
| in4 | - Input 4 | M3 | - Output 3 | GEN | - Generator impulses |
| R-N-EXT | - External potentiometer for speed limitation (50kΩ) | FL | - Sewing foot lifting | | |
| | | ML | - Machine running | | |

Inputs switched to +24V


**ATTENTION!**

When connecting the outputs, ensure that a total power of 70VA constant load will not be exceeded!

- 1) Nominal voltage 24V, no-load voltage max. 36V
- 2) Transistor output with open collector max. 40V, 10mA
- 3) Nominal voltage 15V, $I_{max} = 30mA$
- 4) Nominal voltage 5V, $I_{max} = 20mA$
- *) Front view of the socket (component side) and/or rear view of the plug (soldering side)



Functions of the keys can be selected for all inputs in1, in3 and in4 of the sockets ST2 and B4 using parameters 240, 242 and 243.




LSM001A - Reflection light barrier module

* - Parameter 239 = 0 ➔ The light barrier function has been selected. (Identified when switched to 0V)

** - Parameter 239 = 1...44 ➔ Various input functions are possible on socket B18/5

+5V = Connect pins 1 and 2 on the right with jumper (factory setting)


+15V = Connect pins 3 and 4 on the left with jumper



- 1) Nominal voltage +24V, no-load voltage max. 36V
- 2) Nominal voltage +5V, 100mA (repluggable to +15V, 100mA)

Table: Coding of the Pedal Steps


| Pedal step | D | C | B | A | | |
|------------|---|---|---|---|---------------------------|---------------------------------|
| -2 | H | H | L | L | Full heelback | (e. g. initiating the seam end) |
| -1 | H | H | H | L | Slight heelback | (e. g. sewing foot lifting) |
| 0 | H | H | H | H | Pedal in pos. 0 (neutral) | |
| ½ | H | H | L | H | Pedal slightly forward | (e. g. sewing foot lowering) |
| 1 | H | L | L | H | Speed stage 1 | (n1) |
| 2 | H | L | L | L | Speed stage 2 | |
| 3 | H | L | H | L | Speed stage 3 | |
| 4 | H | L | H | H | Speed stage 4 | |
| 5 | L | L | H | H | Speed stage 5 | |
| 6 | L | L | H | L | Speed stage 6 | |
| 7 | L | L | L | L | Speed stage 7 | |
| 8 | L | L | L | H | Speed stage 8 | |
| 9 | L | H | L | H | Speed stage 9 | |
| 10 | L | H | L | L | Speed stage 10 | |
| 11 | L | H | H | L | Speed stage 11 | |
| 12 | L | H | H | H | Speed stage 12 | (n2) Pedal fully forward |



EB.. Actuator

B11050

4 Connection Scheme of an SM210A Stepping Motor Control




The AB60D.... control (B18) and the SM210A....stepping motor control (B18) are connected by means of adapter cord no. 1113113.

If a light barrier is required for the sewing process, it must be connected to socket B9 on the stepping motor control. The light barrier signal is transmitted via the connecting cable from the SM210A to the sewing drive.

KL2510

Adapter cord for BROTHER model FD3 B257

| | | | |
|-----------------------------------|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 5 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 7 |
| | Input in3 | ➔ | Set parameter 242 = 18 |




*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

Note

Adapter cords nos. 1112816 and 1113132 can only be used for signals with sewing foot lifting and thread trimmer.
 A manual backtack is possible only if one of the outputs M1...M3 is switched to a different function using the corresponding parameter, and the key is connected to one of the inputs in1, in3 or in4 directly on the 37-pin plug.
Input in 2 is not connected!


Adapter cord for JUKI model 5550-6

Setting the functional sequence Thread trimming mode ➔ Set parameter 290 = 14



Adapter cord for JUKI model 5550-7


Setting the functional sequence Thread trimming mode ➔ Set parameter 290 = 14



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.
 **) Front view (component side) of the Molex Minifit plugs.

Adapter cord for JUKI model LU1510-7

| | | | |
|--|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 20 |
| Setting the functions of the keys (Automatic setting) | Input in3 | ➔ | Set parameter 242 = 31 |
| | Input in4 | ➔ | Set parameter 243 = 32 |




in3 = Input speed limitation bit 0 (S1)
in4 = Input speed limitation bit 1 (S2)

*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

**) Front view (component side) of the Molex Minifit plugs.

Adapter cord for KANSAI model RX9803


| | | | |
|-----------------------------------|----------------------|---|-----------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 5 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 7 |



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

Adapter cord for PFAFF models 563, 953, 1050, 1180 without thread monitor


| | | | |
|-----------------------------------|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 0 |
| Setting the functions of the keys | Input in4 | ➔ | Set parameter 243 = 12 |



*) Rear view (soldering side) of 37-pin plug (ST2) and of the remaining sockets.

Adapter cord for PFAFF model 1425

| | | | |
|--|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 13 |
| Setting the functions of the keys (Automatic setting) | Input in1 | ➔ | Set parameter 240 = 2 |
| | Input in3 | ➔ | Set parameter 242 = 24 |
| | Input in4 | ➔ | Set parameter 243 = 11 |




- in1 = Input needle up
- in3 = Input needle moves from position 1 to position 2
- in4 = Input speed limitation n12 with pedal

*) Rear view (soldering side) of 37-pin plug (ST2) and of the remaining sockets.

Adapter cord for PEGASUS model W500/UT

| | | | |
|-----------------------------------|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 5 |
| | Thread trimming mode | ➔ | Set parameter 290 = 17 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 7 |


Attention! If parameters 290 = 17, the lead of socket ST2/34 of the adapter cord below must be resoldered to ST2/37. Cut the lead which was soldered to socket ST2/37. (M1 = Top cover thread cutter, M3 = Stitchlock signal).



Attention! When using this adapter cord on a Pegasus machine, the 9-core cable no. 742373-91 must be removed from the machine!

Adapter cord for PEGASUS backlatch machines


| | | | |
|---|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 8 |
| Setting the functions of the keys (Automatic setting) | Input in1 | ➔ | Set parameter 240 = 6 |
| | Input in3 | ➔ | Set parameter 242 = 10 |



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

Adapter cord for RIMOLDI model F27


| | | | |
|---------------------------------|----------------------|---|-----------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 5 |
|---------------------------------|----------------------|---|-----------------------|



*) Rear view (soldering side) of 37-pin plug (ST2) and of the remaining sockets.

Adapter cord for SINGER models 211, 212 and 591


| | | | |
|--|----------------------|---|-----------------------|
| Setting the functional sequence (Singer models 591, 211U, 212U) | Thread trimming mode | ➔ | Set parameter 290 = 1 |
| Setting the functional sequence (Singer model 212UTT) | Thread trimming mode | ➔ | Set parameter 290 = 2 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 1 |



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

Adapter cord for UNION SPECIAL models CS100 and FS100


| | | | |
|-----------------------------------|----------------------|---|-----------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 4 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 6 |
| | Input in3 | ➔ | Set parameter 242 = 6 |



in1 = Input **machine run blockage** for thread trimming control proximity switch
in3 = Input **machine run blockage** for thread monitor

Adapter cord for UNION SPECIAL model 63900AMZ


| | | | |
|---------------------------------|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 10 |
|---------------------------------|----------------------|---|------------------------|



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

Adapter cord for UNION SPECIAL models 34000 and 36200

| | | | |
|-----------------------------------|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 4 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 6 |
| | Input in3 | ➔ | Set parameter 242 = 6 |
| | Input in4 | ➔ | Set parameter 243 = 18 |




- in1** = Input **machine run blockage** for thread trimming control proximity switch
- in3** = Input **machine run blockage** for thread monitor
- in4** = Input **unlocking the chain** corresponds to function **flatseamer (FLAT-S)**

*) Rear view (soldering side) of 37-pin plug (ST2) and of the remaining sockets.


Adapter cord for YAMATO chainstitch machines VC series

| | | | |
|-----------------------------------|----------------------|---|-----------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 5 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 7 |



Adapter cord for YAMATO chainstitch machines VG series


| | | | |
|-----------------------------------|----------------------|---|-----------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 5 |
| Setting the functions of the keys | Input in1 | ➔ | Set parameter 240 = 7 |



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.


Adapter cord for YAMATO backlatch machine model ABT3

| | | | |
|--|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 9 |
| Setting the functions of the keys (Automatic setting) | Input in1 | ➔ | Set parameter 240 = 6 |
| | Input in3 | ➔ | Set parameter 242 = 10 |



Adapter cord for YAMATO backlatch machine models ABT13 and ABT17


| | | | |
|--|----------------------|---|------------------------|
| Setting the functional sequence | Thread trimming mode | ➔ | Set parameter 290 = 9 |
| Setting the functions of the keys (Automatic setting) | Input in1 | ➔ | Set parameter 240 = 6 |
| | Input in3 | ➔ | Set parameter 242 = 10 |
| | Input in4 | ➔ | Set parameter 243 = 34 |



*) Rear view (soldering side) of 37-pin plug (ST2). Front view (component side) of the remaining plugs/sockets.

5 Timing Diagrams


Mode 0 (lockstitch)



0251/MODE- 0

| Mark | Function | Parameter | Control |
|------|---|--------------------------|------------------|
| | Mode 0 Softstart On Thread trimmer and thread wiper On Signal M1 thread trimmer pos. 1...pos. 1A | 290 = 0 145 = OFF | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |


Mode 1 (lockstitch)



0251/MODE- 1

| Mark | Function | Parameter | Control |
|------|--|-----------|------------------|
| | Mode 1 Softstart On Thread trimmer and thread wiper On | 290 = 1 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |


Mode 2 (lockstitch)



0251/MODE-2

| Mark | Function | Parameter | Control |
|------|--|-----------|------------------|
| | Mode 2 Softstart On Thread trimmer On | 290 = 2 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| tFL | Sewing foot switch-on delay when the thread wiper is off | 211 | |
| tFA | Stop time for thread trimmer | 253 | |
| kt2 | ON period output M2 | 283 | |


Mode 3 (lockstitch)



0251/MODE-3

| Mark | Function | Parameter | Control |
|------|--|-----------|------------------|
| | Mode 3 Softstart On Thread trimmer and thread wiper On | 290 = 3 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| iFA | Thread trimmer activation angle | 250 | |
| FSA | Thread tension release ON period | 251 | |
| FSE | Thread tension release delay depending on angle | 252 | |
| tFA | Stop time for thread trimmer | 253 | |


Mode 4 (chainstitch)



0251/MODE- 4

| Mark | Function | Parameter | Control |
|------|---|------------------------|------------------|
| | Mode 4 Softstart On Thread trimmer and thread wiper On Signal "machine running" M1, M2, M3 Off | 290 = 4 147 = 0 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| tAM | Holding power output M1 of the thread trimmer | 254 | |
| kd1 | Delay time of the thread trimmer backward M1 | 280 | |
| kt1 | ON period of the thread trimmer backward M1 | 281 | |
| kd2 | Delay time of the thread trimmer forward M2 | 282 | |
| kt2 | ON period of the thread trimmer forward M2 | 283 | |
| kd3 | Delay time of the thread wiper M3 | 284 | |
| kt3 | ON period of the thread wiper M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |


Mode 5 (chainstitch) parameter 196 = 0



0251/MODE- 5a

| Mark | Function | Parameter | Control |
|------|--|--------------------|------------------|
| | Mode 5 Chainstitch in general Softstart On Thread trimmer and thread wiper On | 290 = 5 196 = 0 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1 | Delay time of the thread trimmer M1 | 280 | |
| kt1 | ON period of the thread trimmer M1 | 281 | |
| kd2 | Delay time of the thread trimmer M2 | 282 | |
| kt2 | ON period of the thread trimmer M2 | 283 | |
| kd3 | Delay time of the thread wiper M3 | 284 | |
| kt3 | ON period of the thread wiper M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |


Mode 5 (chainstitch) parameter 196 = 1



0251/MODE- 5b

| Mark | Function | Parameter | Control |
|------|---|--------------------|---------|
| | Mode 5 Chainstitch Pegasus Thread trimmer and thread wiper On | 290 = 5 196 = 1 | Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n7 | Trimming speed | 116 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t7 | Delay time until sewing foot On | 206 | |
| kd1 | Delay time output M1 | 280 | |
| kt1 | ON period output M1 | 281 | |
| kd2 | Delay time output M2 for thread trimmer | 282 | |
| kt2 | ON period output M2 for thread trimmer | 283 | |
| kd3 | Delay time output M3 for thread wiper | 284 | |
| kt3 | ON period output M3 for thread wiper | 285 | |


Mode 5 (chainstitch) parameter 273 = ON



0251/MODE- 5c

| Mark | Function | Parameter | Control |
|------|--|---------------------|------------------|
| | Mode 5 Function "initial trimming" On Softstart On Thread trimmer and thread wiper On | 290 = 5 273 = ON | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| Ad1 | Delay time signal M3 at the start of the seam | 274 | |
| At1 | ON period signal M3 at the start of the seam | 275 | |
| Ad2 | Delay time signal M2 at the start of the seam | 276 | |
| At2 | ON period signal M2 at the start of the seam | 277 | |
| Ad3 | Delay time signal M5 at the start of the seam | 278 | |
| At3 | ON period signal M5 at the start of the seam | 279 | |
| kd1 | Delay time of the thread trimmer M1 | 280 | |
| kt1 | ON period of the thread trimmer M1 | 281 | |
| kd2 | Delay time of the thread trimmer M2 | 282 | |
| kt2 | ON period of the thread trimmer M2 | 283 | |
| kdF | Delay time until sewing foot On | 288 | |

Mode 4, 5, 6 or 7 (function “unlocking the chain” with light barrier)




0251/ENTK - 1

| Mark | Function | Parameter | Control |
|------|---|--|------------------|
| in.. | Mode 5 Basic position 2 Thread trimmer On or Off *) Light barrier On Unlocking the chain with pedal in pos. -2 without tape cutting at the seam end Clockwise direction of motor rotation Reverse motor rotation On Unlocking the chain automatically with light barrier Assign the function “unlocking the chain” to one of the inputs in1/in3/in4 | 290 = 5 009 = ON 019 = 3 161 = 0 182 = ON 190 = 2 2.. = 18 | Key S5 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n5 | Speed after light barrier sensing | 114 | |
| LS | Light barrier compensating stitches | 004 | |
| ird | Number of reversing increments | 180 | |
| drd | Switch-on delay of reverse motor rotation | 181 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |

*) When unlocking the chain, the “thread trimming” function is suppressed!

Mode 4, 5, 6 or 7 (function “unlocking the chain”)




0251/ENTK - 2

| Mark | Function | Parameter | Control |
|------|---|---|------------------|
| | Mode 5 Thread trimmer On or Off *) Basic position 2 Clockwise direction of motor rotation Reverse motor rotation On Light barrier On Unlocking the chain manually with pedal in pos. -2 | 290 = 5 161 = 0 182 = ON 009 = ON 190 = 1 | Key S3 Key S5 |
| in1 | Machine run blockage effective with open contact | 240 = 6 | |
| in3 | Automatic speed (n12) without pedal | 242 = 10 | |
| in4 | Function “unlocking the chain” | 243 = 18 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| ird | Number of reversing increments | 180 | |
| drd | Switch-on delay of reverse motor rotation | 181 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |

*) When unlocking the chain, the “thread trimming” function is suppressed!


Mode 6 (chainstitch with tape cutter) parameter 232 = OFF / with clamp parameter 020 = ON



0251/MODE- 6 a

| Mark | Function | Parameter | Control |
|------|--|-----------|---------|
| | Mode 6 | 290 = 6 | |
| | Softstart On | | Key S2 |
| | Thread trimmer and thread wiper On | | Key S3 |
| kLm | Clamp at the seam end On | 020 = ON | |
| ckL | Run-out stitches for clamp at the start of the seam | 021 | |
| | Chainstitch with tape cutter M3 | 232 = OFF | |
| in1 | Tape cutter / fast scissors in the chainstitch and overlock mode | 240 = 15 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1 | Delay time of the thread trimmer M1 | 280 | |
| kt1 | ON period of the thread trimmer M1 | 281 | |
| kd2 | Delay time of the thread wiper M2 | 282 | |
| kt2 | ON period of the thread wiper M2 | 283 | |
| kd3 | Delay time of the tape cutter M3 | 284 | |
| kt3 | ON period of the tape cutter M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |


Mode 6 (chainstitch with fast scissors) parameter 232 = ON



0251/MODE- 6b

| Mark | Function | Parameter | Control |
|------|--|-------------------------------------|------------------|
| in1 | Mode 6 Softstart On Thread trimmer and thread wiper On Chainstitch with fast scissors M2/M3 Tape cutter / fast scissors in the chainstitch and overlock mode | 290 = 6 232 = ON 240 = 15 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1 | Delay time of the thread trimmer M1 | 280 | |
| kt1 | ON period of the thread trimmer M1 | 281 | |
| kd2 | Delay time of output M2 (fast scissors AH1) | 282 | |
| kt2 | ON period of output M2 (fast scissors AH1) | 283 | |
| kd3 | Delay time of output M3 (fast scissors AH2) | 284 | |
| kt3 | ON period of output M3 (fast scissors AH2) | 285 | |
| kdF | Delay time until sewing foot On | 288 | |


Mode 7 (overlock) parameter 232 = OFF (tape cutter) / parameter 018 = OFF (seam end with stop)



0251/MODE-7a

| Mark | Function | Parameter | Control |
|---------|--|-----------|------------------|
| *) | Mode 7 | 290 = 7 | Key S3 Key S4 |
| | Thread trimmer On | | |
| | Sewing foot lifting at the seam end On | | |
| | Counts c1, c2, c3 and c4 On | 000...003 | |
| | Light barrier On | 009 = ON | |
| | Sequence "overlock mode with stop" | 018 = OFF | |
| | Function "pedal in pos. -1 and -2" active in the seam | 019 = 3 | |
| | Clamp at the seam end On | 020 = ON | |
| | Start blockage with light barrier uncovered | 132 = OFF | |
| | Stitch counting at the start of the seam at fixed speed n3 | 143 = 1 | |
| | Stitch counting at the seam end at fixed speed n4 | 144 = 1 | |
| | Seam end after count c2 | 191 = 1 | |
| | Speed n5 effective after light barrier sensing | 192 = OFF | |
| | Chainstitch with tape cutter M3 | 232 = OFF | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n3 | Speed for start counting | 112 | |
| n4 | Speed for end counting | 113 | |
| n5 | Speed after light barrier sensing | 114 | |
| n7 | Trimming speed | 116 | |
| c2 | End counting limited speed until stop | 000 | |
| c1 | Start counting limited speed | 001 | |
| c3 | Start counting tape cutter | 002 | |
| c4 | End counting tape cutter | 003 | |
| LS | Light barrier compensating stitches | 004 | |
| ckL | Run-out stitches clamp at the start of the seam | 021 | |
| t2 | Switch-on delay of sewing foot lifting with pedal in pos. -1 | 201 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1/kd2 | Delay times of outputs M1/M2 | 280/282 | |
| kt1/kt2 | ON periods of outputs M1/M2 | 281/283 | |
| kt3 | ON period tape cutter M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |

*) If parameters 000...003 are set to "0", the respective counts are Off!


Mode 7 (overlock) parameter 232 = ON (fast scissors) / parameter 018 = OFF (seam end with stop)


0251/MODE- 7c

| Mark | Function | Parameter | Control |
|--------------------------------------|--|-----------|------------------|
| *) kLm | Mode 7 | 290 = 7 | Key S3 Key S4 |
| | Thread trimmer On | | |
| | Sewing foot lifting at the seam end On | | |
| | Counts c1, c2, c3 and c4 On | 000...003 | |
| | Light barrier On | 009 = ON | |
| | Sequence "overlock mode with stop" | 018 = OFF | |
| | Function "pedal in pos. -2" thread trimming blocked | 019 = 2 | |
| | Clamp at the seam end Off | 020 = OFF | |
| | Start blockage with light barrier uncovered | 132 = OFF | |
| | Stitch counting at the start of the seam at fixed speed n3 | 143 = 2 | |
| | Stitch counting at the seam end at fixed speed n4 | 144 = 2 | |
| | Seam end after count c2 | 191 = 1 | |
| | Speed n5 after light barrier sensing | 192 = OFF | |
| Chainstitch with fast scissors M2/M3 | 232 = ON | | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n3 | Speed for start counting | 112 | |
| n4 | Speed for end counting | 113 | |
| n5 | Speed after light barrier sensing | 114 | |
| n7 | Trimming speed | 116 | |
| c2 | End counting limited speed until stop | 000 | |
| c1 | Start counting limited speed | 001 | |
| c3 | Start counting tape cutter | 002 | |
| c4 | End counting tape cutter | 003 | |
| LS | Light barrier compensating stitches | 004 | |
| ckL | Run-out stitches clamp at the start of the seam | 021 | |
| t2 | Switch-on delay of sewing foot lifting with pedal in pos. -1 | 201 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1 | Delay time thread trimmer M1 | 280 | |
| kt1 | ON period thread trimmer M1 | 281 | |
| kd2 | Delay time fast scissors M2 | 282 = 0 | |
| kd3 | Delay time fast scissors M3 | 284 = 0 | |
| kt2/kt3 | ON periods of fast scissors M2/M3 | 283/285 | |
| kdF | Delay time until sewing foot On | 288 | |

*) If parameters 000...003 are set to "0", the respective counts are Off!

Mode 7 (overlock) parameter 232 = OFF (tape cutter) / parameter 018 = ON (seam end without stop)




0251/MODE- 7b

| Mark | Function | Parameter | Control |
|---|--|-----------|---------|
| *) | Mode 7 | 290 = 7 | Key S3 |
| | Thread trimmer On | | |
| | Counts c1, c2, c3 and c4 On | 000...003 | |
| | Light barrier On | 009 = ON | |
| | Sequence without stop at the seam end | 018 = ON | |
| | Function "pedal in pos. -1 and -2" active in the seam | 019 = 3 | |
| | Start blockage with light barrier uncovered | 132 = OFF | |
| | Stitch counting at the start of the seam at fixed speed n3 | 143 = 4 | |
| Stitch counting at the seam end at fixed speed n4 | 144 = 4 | | |
| Chainstitch with tape cutter M3 | 232 = OFF | | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n3 | Speed for start counting | 112 | |
| n4 | Speed for end counting | 113 | |
| n5 | Speed after light barrier sensing | 114 | |
| n7 | Trimming speed | 116 | |
| c2 | End counting limited speed until stop | 000 | |
| c1 | Start counting limited speed | 001 | |
| c3 | Start counting tape cutter | 002 | |
| c4 | End counting tape cutter | 003 | |
| LS | Light barrier compensating stitches | 004 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1 | Delay time of thread trimmer M1 | 280 | |
| kt1 | ON period of thread trimmer M1 | 281 | |
| kd2 | Delay time of thread trimmer M2 | 282 | |
| kt2 | ON period of thread trimmer M2 | 283 | |
| kd3 | Delay time of tape cutter M3 | 284 | |
| kt3 | ON period of tape cutter M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |

*) If parameters 000...003 are set to "0" , the respective counts are Off!

Mode 7 (overlock) parameter 232 = OFF (tape cutter) / parameter 018 = OFF / parameter 148 = 1 (sequence with chain suction)




0251/MODE- 7d

| Mark | Function | Parameter | Control |
|------|---|-----------|------------------|
| *) | Mode 7 | 290 = 7 | Key S3 Key S4 |
| | Thread trimmer On | | |
| | Sewing foot lifting at the seam end On | | |
| | Counts c1, c2, c3 and c4 On | 000...003 | |
| | Light barrier On | 009 = ON | |
| | Sequence "overlock mode with stop" | 018 = OFF | |
| | Function "pedal in pos. -1 and -2" active in the seam | 019 = 3 | |
| | Chain suction at the seam end until pedal in pos. 0 (neutral) | 022 = ON | |
| | Start blockage with light barrier uncovered | 132 = OFF | |
| | Output M1 chain suction On (only if parameter 290 = 7) | 148 = 1 | |
| | Unlocking the chain automatically | 190 = 3 | |
| | Seam end after count c2 | 191 = 1 | |
| | Chain suction signal from light barrier uncovered | 193 = ON | |
| | Chainstitch with tape cutter M3 | 232 = OFF | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n3 | Speed for start counting | 112 | |
| n4 | Speed for end counting | 113 | |
| n5 | Speed after light barrier sensing | 114 | |
| n7 | Trimming speed | 116 | |
| c2 | End counting limited speed until stop | 000 | |
| c1 | Start counting limited speed | 001 | |
| c3 | Start counting tape cutter | 002 | |
| c4 | End counting tape cutter | 003 | |
| LS | Light barrier compensating stitches | 004 | |
| t2 | Switch-on delay of sewing foot lifting with pedal in pos. -1 | 201 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd2 | Delay time thread trimmer M2 | 282 | |
| kt2 | ON period thread trimmer M2 | 283 | |
| kt3 | ON period tape cutter M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |

*) If parameters 000...003 are set to "0", the respective counts are Off!

Mode 7 (overlock) parameter 232 = OFF (tape cutter) / parameter 018 = OFF (seam end with pedal in pos. -2 and stop) without light barrier




0251/MODE- 7e

| Mark | Function | Parameter | Control |
|---------------------------------|--|-----------|------------------|
| *) | Mode 7 | 290 = 7 | Key S3 Key S4 |
| | Thread trimmer On | | |
| | Sewing foot lifting at the seam end On | | |
| | Counts c1, c2, c3 and c4 On | 000...003 | |
| | Light barrier Off | 009 = OFF | |
| | Sequence "overlock mode with stop" | 018 = OFF | |
| | Function "pedal in pos. -1 and -2" active in the seam | 019 = 3 | |
| | Clamp at the seam end On | 020 = ON | |
| | Start blockage with light barrier uncovered | 132 = OFF | |
| | Stitch counting at the start of the seam at fixed speed n3 | 143 = 4 | |
| | Stitch counting at the seam end at fixed speed n4 | 144 = 4 | |
| | Seam end after count c2 | 191 = 1 | |
| | Speed n5 effective after light barrier sensing | 192 = OFF | |
| Chainstitch with tape cutter M3 | 232 = OFF | | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n3 | Speed for start counting | 112 | |
| n4 | Speed for end counting | 113 | |
| n5 | Speed after light barrier sensing | 114 | |
| n7 | Trimming speed | 116 | |
| c2 | End counting limited speed until stop | 000 | |
| c1 | Start counting limited speed | 001 | |
| c3 | Start counting tape cutter | 002 | |
| c4 | End counting tape cutter | 003 | |
| LS | Light barrier compensating stitches | 004 | |
| ckL | Run-out stitches clamp at the start of the seam | 021 | |
| t2 | Switch-on delay of sewing foot lifting with pedal in pos. -1 | 201 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| kd1/kd2 | Delay times of outputs M1/M2 | 280/282 | |
| kt1/kt2 | ON periods of outputs M1/M2 | 281/283 | |
| kt3 | ON period tape cutter M3 | 285 | |
| kdF | Delay time until sewing foot On | 288 | |

*) If parameters 000...003 are set to "0", the respective counts are Off!

Mode 8 (backlatch Pegasus)




0251/MODE-8

| Mark | Function | Parameter | Control |
|----------|---|-----------|---------|
| | Mode 8 | 290 = 8 | |
| | Basic position 2 | | Key S5 |
| | Stop in position 2 after the backlatch cycle and speed n_{12} | 026 = 0 | |
| | Softstart On | 134 = ON | Key S2 |
| in1 | Machine run blockage activated with open switch | 240 = 6 | |
| in3 | Automatic speed n_{12} with closed switch | 242 = 10 | |
| n_1 | Positioning speed | 110 | |
| n_2 | Maximum speed | 111 | |
| n_6 | Softstart speed | 115 | |
| n_{12} | Automatic speed | 118 | |
| SSc | Softstart stitches | 100 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |

*) When automatic speed is On, machine run blockage (safety switch) does not work!

Mode 9 (backlatch Yamato) without light barrier




| Mark | Function | Parameter | Control |
|------|---|-----------|---------|
| | Mode 9 | 290 = 9 | |
| | Softstart On | | Key S2 |
| | Basic position 2 | | Key S5 |
| in1 | Machine run blockage activated with open switch | 240 = 6 | |
| in3 | Automatic speed n12 with open switch (the function of input 3 is inverted in mode 9) | 242 = 10 | |
| in4 | Automatic speed n9 | 243 = 34 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n9 | Automatic speed | 122 | |
| n12 | Automatic speed | 118 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |

*) With this setting, machine run blockage (safety switch) has priority over automatic speed n12!

**) Automatic speed n9 has priority over machine run blockage (safety switch)!


Mode 9 (backlatch Yamato) with light barrier



0251/MODE- 9a

| Mark | Function | Parameter | Control |
|------------|--|-----------|------------------|
| in1 in3 | Mode 9 | 290 = 9 | Key S2 Key S5 |
| | Softstart On | | |
| | Light barrier On | 009 = ON | |
| | Basic position 2 | | |
| | Fixed speed n12 cannot be interrupted with pedal in pos. 0 | 141 = 3 | |
| in3 | Machine run blockage activated with open switch | 240 = 6 | |
| | Automatic speed n12 after briefly opening the switch at input 3 and subsequent uncovering of the light barrier | 242 = 10 | |
| | | | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n12 | Automatic speed | 118 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |

Mode 10 (lockstitch)




0251/MODE- 10

| Mark | Function | Parameter | Control |
|------|---|---------------------------|------------------|
| | Mode 10 Softstart On Thread trimmer and thread wiper On Reverse motor rotation Off | 290 = 10 182 = OFF | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| kt1 | ON period of the thread trimmer backward M1 | 281 | |
| kd3 | Delay time of thread tension release M3 | 284 | |
| kt3 | ON period of thread tension release M3 | 285 | |

Time t7 starts only after time kt1 or kt3 has elapsed!


Mode 11 reversal of motor rotation with pedal in pos. -2



0251/MODE- 11

| Mark | Function | Parameter | Control |
|------|--------------------------------------|----------------------|---------|
| in1 | Mode 11 Key for positioning speed | 290 = 11 240 = 20 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| M1 | Signal "reversal of motor rotation" | | |
| M2 | Signal "pedal in pos. -2" | | |
| M3 | Signal "machine running" | | |

Mode 12 reversal of motor rotation with key in3




0251/MODE-12

| Mark | Function | Parameter | Control |
|------|-------------------------------------|-----------|---------|
| in1 | Mode 12 | 290 = 12 | |
| in3 | Key for positioning speed | 240 = 20 | |
| | Key for reversal of motor rotation | 242 = 21 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| M1 | Signal "reversal of motor rotation" | | |
| M2 | Signal "pedal in pos. 0 (neutral)" | | |
| M3 | Signal "machine running" | | |

Note

The signal "machine running" is interrupted for approx. 10ms when pressing the pedal and the key **reversal of motor rotation**.


Mode 13 (lockstitch / Pfaff 1425)



0251/MODE-13

| Mark | Function | Parameter | Control |
|------|--|---------------------------------|---------|
| in4 | Mode 13 Stop for thread trimmer depending on angle Key for limited speed n12 | 290 = 13 197 = 0 243 = 11 | |
| n2 | Maximum speed | 111 | |
| n7 | Trimming speed | 116 | |
| n12 | Limited speed | 118 | |
| ird | Number of reversing increments | 180 | |
| drd | Switch-on delay of reverse motor rotation | 181 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| iFA | Activation angle of the thread trimmer | 250 | |
| FSA | Thread tension release ON period | 251 | |
| FSE | Thread tension release delay depending on angle | 252 | |
| kd3 | Delay time of the thread wiper | 284 | |
| kt3 | ON period of the thread wiper | 285 | |


Mode 13 (lockstitch / Pfaff 1425) special function



0251/MODE- 13 a

| Mark | Function | Parameter | Control |
|------------|---|-----------|---------|
| rd | Mode 13 | 290 = 13 | |
| Frd | Number of reversing increments | 180 = 23 | |
| dr° | Reverse motor rotation On | 182 = ON | |
| $in1$ | Stop for thread trimmer depending on angle | 197 = 86 | |
| | Needle up with subsequent sewing foot lifting with pedal in pos. 0 (neutral) (knee switch at socket B4/1) | 240 = 43 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n7 | Trimming speed | 116 | |
| ird | Number of reversing increments | 180 | |
| drd | Switch-on delay of reverse motor rotation | 181 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| iFA | Activation angle of the thread trimmer | 250 | |
| FSA | Thread tension release ON period | 251 | |
| FSE | Thread tension release delay depending on angle | 252 | |
| kd3 | Delay time of output M3 | 284 | |
| kt3 | ON period of output M3 | 285 | |


Mode 14 (lockstitch)



0251/MODE- 14

| Mark | Function | Parameter | Control |
|------|---|-----------|------------------|
| | Mode 10 Softstart On Thread trimmer and thread wiper On | 290 = 10 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| kd4 | Delay time output M2 | 286 | |
| kt4 | ON period output M2 | 287 | |


Mode 17 (stitch lock Pegasus)



0251/MODE-17


| Mark | Function | Parameter | Control |
|------|--|-----------|---------|
| | Mode 17 Thread trimmer and thread wiper On | 290 = 17 | Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n7 | Trimming speed | 116 | |
| dr° | Stop for thread trimming depending on angle | 197 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| kd1 | Delay time output M1 for top cover thread cutter | 280 | |
| kt1 | ON period output M1 for top cover thread cutter | 281 | |
| kd2 | Delay time output M2 for thread trimmer | 282 | |
| kt2 | ON period output M2 for thread trimmer | 283 | |
| kd3 | Delay time output M3 for stitchlock signal | 284 | |
| kt3 | ON period output M3 for stitchlock signal | 285 | |
| kdF | Delay time until sewing foot On | 288 | |

Mode 18 (Bottoms Overlock)



0251/MODE-18

| Mark | Function | Parameter | Control |
|------|--|---------------------|---------|
| | Mode 18 Automatic sewing foot after light barrier sensing with pedal forward On | 290 = 18 023 = 1 | |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n3 | Speed for start counting (sequence can be selected using parameter 143) | 112 | |
| n4 | Speed for end counting (sequence can be selected using parameter 144) | 113 | |
| n5 | Speed after light barrier sensing | 114 | |
| n7 | Trimming speed | 116 | |
| c2 | End counting limited speed until stop | 000 | |
| c1 | Start counting limited speed | 001 | |
| c4 | End counting for output M1 | 003 | |
| LS | Light barrier compensating stitches | 004 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| kdF | Delay time until sewing foot On | 288 | |

Further Descriptions of Settings If Parameter 290 Is Set to "18" (Mode 18)!**Functions Before Beginning the Seam:**

- Key S2 on the control: softstart On/Off.
- Key S3 on the control does not have any effect.
- Key S4 on the control: sewing foot lifting in the seam or after the seam end On/Off.
- Key S5 on the control: basic position needle up/down.
- With pedal in pos. -2, output M1 is switched off, and with pedal in pos. -1 / 0, switched on again.

Functions When Beginning the Seam:

- When starting the drive, output M2 is switched on immediately and remains on according to the setting of parameter 001 (count c1).
- The speed is limited during the c1 count according to the setting of parameter 112 (speed n3).
- The speed function during the c1 count can be selected using parameter 143.
 - Parameter 143 = 0: Pedal controlled and limited to speed n3.
 - Parameter 143 = 1: Automatic speed n3 without influence by the pedal. The drive stops when the pedal is in pos. 0.
 - Parameter 143 = 2: Limited speed n3; controllable by the pedal up to the set speed.
 - Parameter 143 = 3: Automatic speed n3; can be suspended or interrupted according to the setting of parameter 019.
 - Parameter 143 = 4: Limited speed n3 until covering the light barrier. Then automatic speed.

Functions in the Seam:

- After the c1 count, the speed is pedal controlled up to the set maximum speed.


Functions at the Seam End:

- When the light barrier senses "uncovered", the seam end is initiated. First the light barrier compensating stitches are executed (parameter 004) at the speed n5 (parameter 114).
- The function of speed n5 can be set using parameter 192.
 - Parameter 192 = OFF: Automatic speed n5 without influence by the pedal. The drive stops when the pedal is in pos. 0.
 - Parameter 192 = ON: Pedal controlled and limited to speed n5.
- After the light barrier compensating stitches, output M1 is switched on and remains on according to the setting of parameter 003 (count c4).
- The speed function during the c4 and c2 counts can be selected using parameter 144.
 - Parameter 144 = 0: Pedal controlled and limited to speed n4.
 - Parameter 144 = 1: Automatic speed n4 without influence by the pedal. The drive stops when the pedal is in pos. 0.
 - Parameter 144 = 2: Limited speed n4; controllable by the pedal up to the set speed.
 - Parameter 144 = 3: Automatic speed n4; can be suspended or interrupted according to the setting of parameter 019.
 - Parameter 144 = 4: At the seam end at light barrier speed without influence by the pedal. Stop with pedal in pos. 0.
- After the c4 count, output M1 is switched off and output M2 switched on. Output M2 remains on according to the setting of parameter 000 (count c2). After switching off output M2, the drive stops in position 2.
- All counts can be suspended with pedal in pos. -2, if parameter 019 is set to "3". All counts are skipped and the drive stops in position 2.

Functions after Drive Standstill:

- After drive standstill, the sewing foot is lifted automatically after a delay kdf (parameter 288) according to the setting of parameter 023 if the pedal is forward, until the pedal is pressed to position 0 (neutral). If key S4 on the control is set accordingly, the sewing foot may also remain lifted after the seam end. The setting with S4 has priority over the setting with parameter 023.

Mode 19 (lockstitch Macofrey)




0251/MODE- 19

| Mark | Function | Parameter | Control |
|------|---|-------------------------|------------------|
| | Mode 19 Softstart On Thread trimmer and thread wiper On Signal "backtacking" Off | 290 = 19 148 = 0 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| tAM | Holding power output M1 of the thread trimmer backward | 254 | |
| kt1 | ON period of the thread trimmer backward M1 | 281 | |
| kd3 | Delay time of the thread wiper M3 | 284 | |
| kt3 | ON period of the thread wiper M3 | 285 | |

Time t7 starts only after time kt1 or kt3 has elapsed!


Mode 20 (lockstitch Juki LU1510-7)



0251 / MODE- 20

| Mark | Function | Parameter | Control |
|------|---|-----------|---------|
| | Mode 20 | 290 = 20 | |
| | Softstart On | | Key S2 |
| | Thread trimmer and thread wiper On | | Key S3 |
| in3 | Speed limitation bit 0 | 242 = 31 | |
| in4 | Speed limitation bit 1 | 243 = 32 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| n9 | Automatic speed | 122 | |
| n10 | Automatic speed | 117 | |
| n11 | Automatic speed | 123 | |
| SSc | Softstart stitches | 100 | |
| ird | Number of reversing increments | 180 | |
| drd | Switch-on delay of reverse motor rotation | 181 | |
| dr° | Stop for thread trimming depending on angle | 197 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t4 | Full power of sewing foot lifting | 203 | |
| t5 | Pulsing of sewing foot lifting | 204 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| iFA | Activation angle of the thread trimmer | 250 | |
| FSA | Thread tension release ON period | 251 | |
| FSE | Thread tension release delay depending on angle | 252 | |
| kd3 | Delay time of thread wiper M3 | 284 | |
| kt3 | ON period of thread wiper M3 | 285 | |

Mode 22 (lockstitch / Brother model B-891)



0251/MODE- 22

| Mark | Function | Parameter | Control |
|------|---|-----------|------------------|
| | Mode 22 Softstart On Thread trimmer and thread wiper On | 290 = 22 | Key S2 Key S3 |
| n1 | Positioning speed | 110 | |
| n2 | Maximum speed | 111 | |
| n6 | Softstart speed | 115 | |
| n7 | Trimming speed | 116 | |
| SSc | Softstart stitches | 100 | |
| t3 | Start delay from lifted sewing foot | 202 | |
| t6 | Thread wiper ON period | 205 | |
| t7 | Sewing foot switch-on delay after thread wiper | 206 | |
| iFA | Activation angle of the thread trimmer | 250 | |
| FSA | Thread tension release ON period | 251 | |
| FSE | Thread tension release delay depending on angle | 252 | |
| tFA | Stop time for thread trimmer | 253 | |

6 List of Parameters

6.1 Preset Values Depending on Mode

The preset values which are different in the various modes are listed in the table below. When switching the mode using parameter 290, these values change automatically.

Operator Level

| Mode → Parameter | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 17 | 18 | 19 | 20 | 22 |
|---------------------|---|---|---|---|---|---|---|----|-----|-----|----|-----|-----|----|----|----|-----|----|----|----|
| 000 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 70 | - | - | - |
| 001 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 10 | - | - | - |
| 003 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 10 | - | - | - |
| 004 | - | - | - | - | - | - | - | 0 | - | - | - | - | - | - | - | - | 20 | - | - | - |
| 005 | - | - | - | - | 0 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 009 | - | - | - | - | - | - | - | ON | - | - | - | - | - | - | - | - | ON | - | - | - |
| 013 | - | - | - | - | - | - | - | - | OFF | OFF | - | OFF | OFF | - | - | - | OFF | - | - | - |
| 014 | - | - | - | - | - | - | - | - | OFF | OFF | - | OFF | OFF | - | - | - | OFF | - | - | - |
| 019 | - | - | - | - | - | - | - | 2 | - | - | - | - | - | - | - | - | 1 | - | - | - |

Technician Level

| Mode → Parameter | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 17 | 18 | 19 | 20 | 22 |
|---------------------|---|---|---|---|------|---|---|-----|------|-----|------|----|----|------|----|----|------|------|------|------|
| 100 | - | - | - | - | - | - | - | - | - | - | 1 | - | - | - | - | - | - | 1 | - | - |
| ** 110 | - | - | - | - | 180 | - | - | - | 250 | 250 | 180 | - | - | 180 | - | - | - | 180 | - | - |
| ** 111 | - | - | - | - | 5000 | - | - | - | - | - | 4500 | - | - | 3000 | - | - | - | 4500 | 2500 | 3500 |
| ** 112 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 4000 | - | - | 900 |
| ** 113 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 1200 | - | - | 900 |
| ** 115 | - | - | - | - | - | - | - | - | - | - | 600 | - | - | - | - | - | - | 600 | - | - |
| ** 116 | - | - | - | - | - | - | - | - | - | - | - | - | - | 180 | - | - | - | - | - | - |
| ** 117 | - | - | - | - | - | - | - | - | - | - | - | - | - | 2000 | - | - | - | - | 1800 | - |
| ** 118 | - | - | - | - | - | - | - | - | - | - | - | - | - | 3000 | - | - | - | - | 2500 | - |
| ** 122 | - | - | - | - | - | - | - | - | 6000 | - | - | - | - | 2600 | - | - | - | - | - | - |
| ** 123 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 2400 | - |
| ** 124 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 3500 |
| ** 125 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 2000 |
| 126 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 1 |
| 130 | - | - | - | - | - | - | - | ON | - | - | - | - | - | - | - | - | - | - | - | - |
| 132 | - | - | - | - | - | - | - | OFF | - | - | - | - | - | - | - | - | - | - | - | - |
| 134 | - | - | - | - | - | - | - | - | - | - | ON | - | - | - | - | - | - | ON | ON | - |
| 147 | - | - | - | - | - | - | - | - | - | - | - | 3 | 3 | - | - | - | - | - | - | - |
| 148 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 3 | - |
| 153 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 3 | - |
| 161 | - | - | - | - | 0 | 0 | 0 | 0 | 0 | 0 | 0 | - | - | - | - | 0 | - | - | - | - |
| 180 | - | - | - | - | - | - | - | - | - | - | 7 | - | - | 1 | - | - | - | - | 10 | 14 |
| 181 | - | - | - | - | - | - | - | - | - | - | 230 | - | - | - | - | - | - | - | - | - |
| 182 | - | - | - | - | - | - | - | ON | - | - | ON | - | - | ON | - | - | - | - | ON | ON |
| 190 | - | - | - | - | 0 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 192 | - | - | - | - | - | - | - | ON | - | - | - | - | - | - | - | - | - | - | - | - |
| 197 | - | - | - | - | - | - | - | - | - | - | - | - | - | 0 | - | - | - | - | 50 | - |

- = For the positions marked with “-“ the preset values listed in the List of Parameters are used !

** = When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

Supplier Level

| Mode → Parameter | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 17 | 18 | 19 | 20 | 22 | |
|---------------------|---|---|---|---|-----|---|---|-----|----|----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|---|
| 201 | - | - | - | - | 160 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 202 | - | - | - | - | - | - | - | - | 0 | 0 | 10 | - | - | - | - | - | - | - | 10 | - | - |
| 203 | - | - | - | - | 350 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - |
| 204 | - | - | - | - | - | - | - | - | - | - | 1 | - | - | - | - | - | - | - | 1 | - | - |
| ** 205 | - | - | - | - | - | - | - | - | - | - | 240 | - | - | - | - | - | - | - | 240 | - | - |
| 206 | - | - | - | - | - | - | - | - | - | - | 150 | - | - | - | - | - | - | - | 150 | - | - |
| 211 | - | - | - | - | - | - | - | - | - | - | - | - | - | 100 | - | - | - | - | - | - | - |
| 231 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | OFF | - | - | - | - |
| 239 | - | - | - | - | - | - | - | - | - | 10 | - | - | - | - | - | - | - | - | - | - | - |
| 240 | - | - | - | - | 6 | - | - | - | 6 | 6 | - | 20 | 20 | 2 | - | - | - | 16 | 13 | 12 | - |
| 242 | - | - | - | - | 3 | - | - | - | 10 | 10 | - | - | 21 | 24 | - | - | - | 1 | 31 | 2 | - |
| 243 | - | - | - | - | - | - | - | - | - | 34 | - | - | - | 11 | - | - | - | - | 32 | 14 | - |
| 250 | - | - | - | - | - | - | - | - | - | - | - | - | - | 70 | - | - | - | - | - | 20 | - |
| 251 | - | - | - | - | - | - | - | - | - | - | - | - | - | 110 | - | - | - | - | - | 100 | - |
| 252 | - | - | - | - | - | - | - | - | - | - | - | - | - | 70 | - | - | - | - | - | 60 | - |
| ** 253 | - | - | - | - | - | - | - | - | - | - | - | - | - | 0 | - | - | - | - | - | 0 | - |
| 254 | - | - | - | - | - | - | - | - | - | - | 4 | - | - | 0 | - | - | - | - | 8 | - | - |
| ** 280 | x | x | x | x | 100 | - | - | 100 | x | x | x | x | x | x | x | 100 | - | - | - | - | - |
| ** 281 | x | x | x | x | - | - | - | - | x | x | 280 | x | x | x | x | - | - | 280 | - | - | - |
| ** 282 | x | x | 0 | x | 0 | - | - | 200 | x | x | x | x | x | x | x | - | - | - | - | - | - |
| ** 283 | - | - | - | - | 200 | - | - | - | x | x | x | x | x | x | x | - | - | - | - | - | - |
| ** 284 | x | x | x | x | - | - | 0 | 0 | x | x | 150 | 100 | 100 | 0 | x | 200 | - | 150 | 100 | - | - |
| ** 285 | x | x | x | x | 200 | - | - | - | x | x | 70 | x | x | 120 | x | 70 | - | 70 | - | - | - |
| ** 286 | x | x | x | x | - | - | 0 | - | x | x | x | x | x | x | x | - | - | - | - | - | - |
| ** 288 | x | x | x | x | 500 | - | - | - | x | x | x | x | x | - | - | 200 | 0 | - | - | - | - |
| 297 | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 2 | - | - | - | - |
| Basic pos. | 1 | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 1 | 2 | 2 | 1 | 1 | 2 | 1 | 1 | 1 | 1 | 1 |

Note

The preset values of the following list of parameters refer to the setting of parameter 290 = 0.

- x = The positions marked with "x" are not used in the functional sequence!
 - = For the positions marked with "-" the preset values listed in the List of Parameters are used !
 ** = When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

6.2 Operator Level

The preset values of the following list of parameters refer to the setting of parameter 290 = 0.

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|---|----------|------------|-----|--------|------|
| 000 | c2 - Stitch counting - End counting limited speed until stop | stitches | 254 | 0 | 2 *) | A |
| 001 | c1 - Stitch counting - Start counting limited speed n3 | stitches | 254 | 0 | 2 *) | A |
| 002 | c3 - Stitch counting - Counting tape cutter at the start of the seam | stitches | 254 | 0 | 2 *) | A |
| 003 | c4 - Stitch counting - Counting tape cutter at the seam end | stitches | 254 | 0 | 2 *) | A |
| 004 | LS Light barrier compensating stitches | stitches | 254 | 0 | 7 *) | A |
| 005 | Number of stitches of the light barrier filter for knitted fabrics | stitches | 254 | 0 | 1 *) | A |
| 006 | Number of light barrier seams | | 15 | 1 | 1 | A |
| 007 | Number of stitches for the seam with stitch counting | stitches | 254 | 0 | 20 | A |
| 009 | LS Light barrier On/Off | ON/OFF | | | OFF *) | A |
| 013 | Thread trimmer On/Off | ON/OFF | | | ON *) | A |
| 014 | Thread wiper On/Off | ON/OFF | | | ON *) | A |
| 015 | Stitch counting On/Off | ON/OFF | | | OFF | A |
| 018 | OFF = Sequence "overlock mode with stop" ON = Sequence "overlock mode without automatic stop." | ON/OFF | | | OFF | A |
| 019 | 0 = Pedal in pos. -1 blocked in the seam; with pedal in pos. -2 in the seam, only sewing foot lifting is possible. (Function only if parameter 009 = ON) 1 = Pedal in pos. -1, sewing foot lifting blocked in the seam. 2 = Pedal in pos. -2, thread trimming blocked. (Function only if parameter 009 = ON) 3 = Pedal in pos. -1 and -2 active in the seam. 4 = Pedal in pos. -1 and -2 blocked in the seam. (Function only if parameter 009 = ON) | | 4 | 0 | 3 *) | A |
| 020 | kLM Clamp at the seam end On/Off | ON/OFF | | | OFF | A |
| 021 | ckL Run-out stitches clamp at the start of the seam (Parameter 290 = 6 and 7) | stitches | 254 | 0 | 2 *) | A |
| 022 | OFF = Chain suction until the end of count c2 ON = Chain suction at the seam end until pedal in pos. 0 (neutral) | ON/OFF | | | OFF | A |
| 023 | Automatic sewing foot lifting with pedal forward at the seam end, if light barrier or stitch counting is switched on. 0 = Automatic sewing foot Off 1 = Automatic sewing foot On | | 1 | 0 | 1 | A |
| 024 | Thread tension release with sewing foot lifting, if parameter 290 = 13 and thread trimmer is switched off. 0 = Thread tension release with sewing foot only at the seam end 1 = Thread tension release with sewing foot at intermediate stop and at the seam end | | 1 | 0 | 1 | A |
| 026 | Switchable stop for Pegasus backlatch machines if parameter 290 = 8 0 = Stop in position 2 after the backlatch cycle and speed n12 1 = Stop always in position 1 | | 1 | 0 | 0 | B |
| 030 | 0 = Bobbin thread monitor Off 1 = Bobbin thread monitor with stop 2 = Bobbin thread monitor without stop 3 = Bobbin thread monitor with stop and start blockage after thread trimming | | 3 | 0 | 0 | A |
| 031 | Number of stitches for bobbin thread monitor | stitches | 25500 ***) | 0 | 0 | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

***) When programming the 5-digit (max) parameter values on the control, the 3-digit value displayed must be multiplied by 100.

6.3 Technician Level

Code no. 190 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. | |
|-----------|-------------|--|----------|------------|--------|---------|---|
| 100 | SSc | Number of softstart stitches | stitches | 254 | 0 | 2 *) | A |
| 110 | n1 | Positioning speed | RPM | 390 **) | 70 | 200 *) | A |
| 111 | n2 | Upper limit setting range of the maximum speed | RPM | 9900 **) | n2_ | 4000 *) | A |
| 112 | n3 | Stitch counting speed at the start of the seam | RPM | 9900 **) | 200 | 1200 *) | A |
| 113 | n4 | Stitch counting speed at the seam end | RPM | 9900 **) | 200 | 1200 *) | A |
| 114 | n5 | Speed after light barrier sensing | RPM | 9900 **) | 200 | 1200 *) | A |
| 115 | n6 | Softstart speed | RPM | 2550 **) | 70 | 500 *) | A |
| 116 | n7 | Trimming speed | RPM | 500 **) | 70 | 200 *) | A |
| 117 | n10 | High lift walking speed | RPM | 9900 **) | 400 | 1000 *) | A |
| 118 | n12 | Automatic speed for stitch counting | RPM | 9900 **) | 400 | 3500 *) | A |
| 119 | | Speed stage graduation 1 = linear 2 = slightly progressive 3 = highly progressive | | 3 | 1 | 2 *) | A |
| 121 | n2_ | Lower limit setting range of the maximum speed | RPM | n2- **) | 400 | 400 | A |
| 122 | n9 | Limited speed n9 | RPM | 9900 **) | 400 | 2000 *) | A |
| 123 | n11 | Limited speed n11 | RPM | 9900 **) | 400 | 2500 *) | A |
| 124 | | Speed limitation by means of ext. potentiometer (maximum value) | RPM | 9900 **) | Pa.125 | 4000 *) | A |
| 125 | | Speed limitation by means of ext. potentiometer (minimum value) Note: The lower speed will be reached only if the value of parameter 110 ≤ value of parameter 125. | RPM | Pa.124 **) | 100 | 400 *) | A |
| 126 | | Function "speed limitation by means of external potentiometer" 0 = Function "external potentiometer" Off 1 = External potentiometer always active 2 = External potentiometer active only if one of inputs in1, in3, in4 has been selected and activated | | 2 | 0 | 0 *) | A |
| 128 | | Start delay, when command "start" is given by covering the light barrier (see parameter 129) | ms | 2000 **) | 0 | 0 | A |
| 129 | | Machine start by covering the light barrier OFF = Function Off ON = Machine start by covering the light barrier (only in conjunction with parameter 132 = ON) | ON/OFF | | | OFF | A |
| 130 | | Light barrier filter for knitted fabrics | ON/OFF | | | OFF *) | A |
| 131 | | OFF = Light barrier sensing "covered" ON = Light barrier sensing "uncovered" | ON/OFF | | | ON *) | A |
| 132 | | OFF = Machine start possible with light barrier uncovered or covered. ON = Machine start blocked with light barrier uncovered | ON/OFF | | | ON *) | A |
| 133 | | Thread trimming when completing the seam after light barrier sensing On/Off | ON/OFF | | | ON *) | A |
| 134 | | Softstart On/Off | ON/OFF | | | OFF *) | A |
| 137 | | High lift for walking foot / flip-flop 1 On/Off | ON/OFF | | | ON *) | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

***) When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

Technician Level

Code no. 190 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|--|--------|-----|-----|--------|------|
| 141 | Speed status for the seam with stitch counting 0 = Speed controllable by the pedal up to the set maximum speed (parameter 111) 1 = Fixed speed (parameter 118) without influence by the pedal. Machine stop by pressing the pedal to the basic position. 2 = Limited speed controllable by the pedal up to the set speed (parameter 118) 3 = At fixed speed (parameter 118) can be interrupted by full heelback | | 3 | 0 | 0 | A |
| 142 | Speed status for the free seam and for the seam with light barrier 0 = Speed controllable by the pedal up to the set maximum speed (parameter 111) 1 = Fixed speed (parameter 118) without influence by the pedal. Machine stop by pressing the pedal to the basic position. 2 = Limited speed controllable by the pedal up to the set limit (parameter 118) 3 = At fixed speed (parameter 118) can be interrupted by full heelback (only for seams with light barrier). | | 3 | 0 | 0 | A |
| 143 | Stitch counting at the start of the seam 0 = Speed controllable by the pedal up to the set maximum speed (parameter 111) 1 = Fixed speed (parameter 112) without influence by the pedal. Machine stop by pressing the pedal to the basic position. 2 = Limited speed controllable by the pedal up to the set limit (parameter 112) 3 = At fixed speed (parameter 112), can be suspended or interrupted depending on the setting of parameter 019. 4 = Limited speed controllable by the pedal up to light barrier covered. Then fixed speed (parameter 112). Machine stop by pressing the pedal to the basic position. | | 4 | 0 | 2 *) | A |
| 144 | Stitch counting at the seam end 0 = Speed controllable by the pedal up to the set maximum speed (parameter 111) 1 = Fixed speed (parameter 113) without influence by the pedal (machine stop by pressing the pedal to the basic position) 2 = Limited speed controllable by the pedal up to the set limit (parameter 113) 3 = At fixed speed (parameter 113), can be suspended or interrupted depending on the setting of parameter 019. 4 = At the seam end at light barrier speed without influence by the pedal. Stop with pedal in pos. 0. Chain suction at fixed speed (parameter 113) without influence by the pedal is performed at the seam end with pedal in pos. -2 until stop. | | 4 | 0 | 2 *) | A |
| 145 | OFF = Signal M1 trimming pos.1...pos.1A ON = Signal M1 trimming pos.1...pos.2 (effective only if parameter 290 = 0) | ON/OFF | | | OFF | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

Technician Level

Code no. 190 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|--|------|----------|-----|--------|------|
| 146 | 0 = Signal high lift for walking foot Off 1 = Signal high lift for walking foot at output M1 2 = Signal high lift for walking foot at output M2 3 = Signal high lift for walking foot at output M3, if parameter 297 = 0 The connection of adapter cord and high lift walking solenoid may have to be corrected according to the setting of outputs M1...M3. See connection diagram and adapter cable routing! | | 3 | 0 | 0 | A |
| 147 | 0 = Signal machine running Off (exception M5) 1 = Signal machine running at output M1 2 = Signal machine running at output M2 3 = Signal machine running at output M3, if parameter 297 = 0 The connection of adapter cord and solenoid valve machine running may have to be corrected according to the setting of outputs M1...M3. See connection diagram and adapter cable routing! | | 3 | 0 | 0 *) | A |
| 148 | 0 = Signal backtacking Off 1 = Signal backtacking at output M1 2 = Signal backtacking at output M2 3 = Signal backtacking at output M3, if parameter 297 = 0 If parameter 290 = 7, the selected output takes the function chain suction . The connection of adapter cord and backtacking solenoid may have to be corrected according to the setting of outputs M1...M3. See connection diagram and adapter cable routing! | | 3 | 0 | 0 *) | A |
| 152 | thP Run-out time of the high lift walking speed | ms | 500 | 80 | 150 | A |
| 153 | Braking power at machine standstill | | 50 | 0 | 10 *) | A |
| 155 | Mode signal "run" 0 = Signal Off. 1 = Signal "run" On. 2 = Signal "run" switched on when the speed is >3000 RPM. 3 = Signal with pedal <> 0. | | 3 | 0 | 1 | A |
| 156 | t05 Switch-off delay for the signal "run" | ms | 2550 **) | 0 | 0 | A |
| 161 | Direction of motor rotation 0 = Clockwise rotation 1 = Counterclockwise rotation | | 1 | 0 | 1 *) | A |
| 172 | POS Display on the control: Pos. 1 to 1A (LED 7 lights up) Pos. 2 to 2A (LED 8 lights up) | | | | | |
| 173 | Checking of the signal outputs and inputs using the incorporated control panel 01 = Free on socket ST2/34 02 = Sewing foot lifting on socket ST2/35 03 = Output M1 on socket ST2/37 04 = Output M3 on socket ST2/27 05 = Output M2 on socket ST2/28 06 = Free 07 = Output ML or M5 on socket ST2/32 OFF/ON = By actuating the switches connected to the control, the function of these switches is checked and displayed on the control. OFF is displayed with open switch and ON with closed switch. | | | | | |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

***) When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

Technician Level

Code no. 190 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|--|----------|----------|-----|--------|------|
| 179 Sr5 | Control program number with index and identification number. Upon pressing the appropriate key the data will be displayed in succession. Control display: Press the E key → Display e. g. 467 Press the >> key → Display e. g. h Press the >> key → Display e. g. 00 Press the >> key → Display e. g. 04 Press the >> key → Display e. g. 20 Press 2x the P key → Display shows no reading | | | | | |
| 180 ird | Number of reversing increments | incr. | 100 | 0 | 60 *) | A |
| 181 drd | Switch-on delay of reverse motor rotation | ms | 990 | 0 | 10 *) | A |
| 182 | Reverse motor rotation On/Off | ON/OFF | | | OFF *) | A |
| 183 | Switching off the flip-flop functions at the seam end 0 = Flip-flop 1 not switched off at the seam end 1 = Flip-flop 1 switched off at the seam end | | 1 | 0 | 0 | A |
| 184 c6 | Number of run-out stitches when unlocking the chain (effective only if parameter 190 = 3 and 290 = 7) | stitches | 254 | 0 | 20 *) | A |
| 185 chP | Stitch counting high lift for walking foot | stitches | 254 | 0 | 0 | A |
| 190 | Function "unlocking the chain" in modes 4, 5, 6 and 7 (parameter 290) 0 = Unlocking the chain Off 1 = Unlocking the chain manually (with pedal in pos. -2 without cutting at the seam end) 2 = Unlocking the chain automatically - with light barrier or - pedal in pos. -2 (parameter 019) without cutting at the seam end 3 = Unlocking the chain automatically - with light barrier or - pedal in pos. -2 (parameter 019) with cutting and run-out stitches (parameter 184) at the seam end, then unlocking the chain (only if parameter 290 = 7) | | 4 | 0 | 2 *) | A |
| 191 | Seam end in the overlock mode by end count c2 or c4 0 = Seam end after count c4 – tape cutter 1 = Seam end after count c2 – chain suction | | 1 | 0 | 0 | A |
| 192 | Speed of the light barrier compensating stitches OFF = Speed n5 after light barrier sensing ON = Speed pedal controlled | ON/OFF | | | OFF *) | A |
| 193 | Enable chain suction signal OFF = Chain suction signal after the light barrier compensating stitches ON = Chain suction signal from light barrier uncovered onwards | ON/OFF | | | OFF | A |
| 195 | Stitches for light barrier monitoring (light barrier monitoring is off, when set to "0"). | stitches | 2550 **) | 0 | 0 | A |
| 196 | Function "chainstitch thread trimmer" (only if parameter 290 = 5) 0 = Chainstitch thread trimmer in general 1 = Chainstitch thread trimmer Pegasus | | 1 | 0 | 0 *) | A |
| 197 dr° | Stop for thread trimming depending on angle | degrees | 510 | 0 | 360 *) | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

**) When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

+

6.4 Supplier Level

Code no. 311 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. | |
|-----------|-------------|--|--------|----------|--------|--------|---|
| 201 | t2 | Sewing foot lift switch-on delay with half heelback | ms | 500 | 20 | 80 *) | A |
| 202 | t3 | Start delay after switching off the sewing foot lift signal | ms | 500 | 0 | 50 *) | A |
| 203 | t4 | Time of full power of sewing foot lifting | ms | 600 | 0 | 500 *) | A |
| 204 | t5 | Holding power for sewing foot lifting Stages 0...7 Stage 1 → 12.5% low holding power Stage 7 → 87.5% Stage 0 → 100% high holding power | | | | 3 *) | A |
| 205 | t6 | Thread wiper time | ms | 2550 **) | 0 | 120 *) | A |
| 206 | t7 | Delay from end of thread wiper until sewing foot lifting On | ms | 800 | 0 | 40 *) | A |
| 207 | | Braking effect when modifying the preset value ≤ 4 stages | | 64 | 1 | 25 | A |
| 208 | | Braking effect when modifying the preset value ≥ 5 stages | | 64 | 1 | 64 | A |
| 211 | tFL | Sewing foot lift switch-on delay with thread wiper off | ms | 500 | 0 | 60 *) | A |
| 220 | | Accelerating power of the drive | | 255 | 1 | 32 | A |
| 221 | | Speed gate 1 | RPM | 990 **) | 50 | 100 | A |
| 222 | | Speed gate damping period (effective only if parameter 224 = OFF) | ms | 990 | 0 | 0 | A |
| 223 | | Speed gate 2 | RPM | 6500 **) | 500 | 1700 | A |
| 224 | | Speed gate 2 On/Off | ON/OFF | | | ON | A |
| 231 | | Execution of the first stitch after Power On at positioning speed | ON/OFF | | | ON *) | A |
| 232 | | Overlock with fast scissors On/Off OFF = Tape cutter ON = Fast scissors (set parameter 282 = 0) | ON/OFF | | | OFF | A |
| 233 | | Error message A1, if the pedal is not in pos. 0 (neutral), when switching the machine on. OFF = Error message A1 is suppressed (e. g. with automats) ON = Error message A1 is displayed | ON/OFF | | | ON | A |
| 234 | | New start after machine run blockage OFF = New start after deactivating the machine run blockage without influence by the pedal (e. g. with automats) ON = New start after deactivating the machine run blockage only if pedal in pos. 0 | ON/OFF | | | ON | A |
| 236 | | 0 = Sewing foot lift possible in all positions 1 = Sewing foot lift possible in position 2 2 = Sewing foot lift at the seam end stored with pedal backward. Storing undone with pedal slightly forward. | | 2 | 0 | 0 | A |
| 238 | | Software debouncing for all inputs: 0 = No debouncing 1 = With debouncing | | 1 | 0 | 1 *) | A |
| 239 | FEL | Selection of the input function on socket B18/5 0 = Light barrier function, if 009 = ON All other functions as with parameter 240. Exception is parameter 239 = 14. At this setting, high lift for walking foot is performed with speed limitation <u>operational mode not stored</u> . | | 44 | 0 | 0 *) | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

***) When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

Supplier Level

Code no. 311 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|---|------|-----|-----|--------|------|
| 240 in1 | Selection of the input functions on socket ST2/7 and B4/1 for input 1. A value is preset for a number of modes. See chapter "Preset Values Depending on Mode" 0 = No function 1 = Needle up/down 2 = Needle up 3 = Single stitch (basting stitch) 4 = Full stitch 5 = Needle to position 2 6 = Machine run blockage effective with open contact 7 = Machine run blockage effective with closed contact 8 = Machine run blockage unpositioned effective with open contact 9 = Machine run blockage unpositioned effective with closed contact 10 = Automatic speed n12 without pedal 11 = Limited speed n12 pedal controlled 12 = Sewing foot lifting with pedal in position 0 (neutral) 13 = High lift for walking foot with speed limitation n10 (operational mode not stored) 14 = High lift for walking foot (flip-flop 1) with speed limitation n10 (operational mode stored) 15 = Tape cutter / fast scissors (in chainstitch and overlock mode) 16 = Intermediate backtack / intermediate stitch condensing 17 = No function 18 = Unlocking the chain (can be activated by keystroke, but will be executed only at the seam end) 19 = Set counter of bobbin thread monitor 20 = Positioning speed n1 21 = Reversal of motor rotation (possible only if parameter 290 = 12) 22 = No function 23 = Speed limitation n9 24 = Needle moves from position 1 to position 2 (flip-flop 3). If the needle is outside of position 1, machine start is blocked for safety reasons and the sewing foot is immediately lifted. 25 = Speed limitation with ext. potentiometer On/Off (see parameter 126) 26 = No function 27 = Unlocking the chain (the function is performed upon pressing the key). 28 = External light barrier 29 = No function 30 = No function 31 = Function "speed limitation bit0" (speed n11) 32 = Function "speed limitation bit1" (speed n10) (Bit0 + Bit1 = Speed n9) 33 = Speed n9 pedal controlled 34 = Automatic speed n9 can be suspended by pressing the pedal to pos. 0 35 = Automatic speed n9 can be interrupted by pressing the pedal to pos. -2 36 = Automatic speed n9 without pedal 37 = No function 38 = No function | | 44 | 0 | 0 *) | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

Supplier Level

Code no. 311 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|--|--------|----------|-----|--------|------|
| | 39 = No function 40 = No function 41 = No function 42 = No function 43 = Needle up with subsequent sewing foot lifting with pedal in pos. 0 (neutral) 44 = Seam end as with pedal in pos. -2 | | | | | |
| 242 | in3 Selection of the input function on socket ST2/6 and B4/4 for input 3 0 = No function All other functions of the keys as with parameter 240 | | 44 | 0 | 0 *) | A |
| 243 | in4 Selection of the input function on socket ST2/8 and B4/5 for input 4 0 = No function All other functions of the keys as with parameter 240 | | 44 | 0 | 0 *) | A |
| 250 | iFA Thread trimmer activation angle (1 increment = 1.5°) | incr. | 120 | 0 | 100 *) | A |
| 251 | FSA Switch-off delay of thread tension release | ms | 990 | 0 | 50 *) | A |
| 252 | FSE Switch-on delay of thread tension release (1 increment = 1.5°) | incr. | 120 | 0 | 0 *) | A |
| 253 | tFA Stop time for thread trimmer | ms | 2550 **) | 0 | 70 *) | A |
| 254 | tAM Holding power output M1 of the thread trimmer backward (stages 0...9) Stage 0 = Holding power Off Stage 1 = 6.25% Stage 2 = 12.5% Stage 3 = 18.75% Stage 4 = 25% Stage 5 = 31,25% Stage 6 = 37,5% Stage 7 = 43,75% Stage 8 = 50% Stage 9 = 100% (full power) | | 9 | 0 | 2 *) | A |
| 263 | High lift for walking foot operational mode not stored with input in.. = 13 0 = Signal "high lift for walking foot", when key is closed. 1 = Signal "high lift for walking foot", when key is open. (Function effective if parameter 137 = ON) | | 1 | 0 | 0 | A |
| 266 | Limited speed n12 input in.. = 11 0 = Speed limitation n12, when key is closed. 1 = Speed limitation n12, when key is open. | | 1 | 0 | 0 | A |
| 273 | Trimming function at the start of the seam On/Off (only if parameter 290 = 5) | ON/OFF | | | OFF | A |
| 274 | Ad1 Delay time of signal M3 at the start of the seam | ms | 2550 **) | 0 | 40 | A |
| 275 | At1 ON period of signal M3 at the start of the seam | ms | 2550 **) | 0 | 150 | A |
| 276 | Ad2 Delay time of signal M2 at the start of the seam | ms | 2550 **) | 0 | 50 | A |
| 277 | At2 ON period of signal M2 at the start of the seam | ms | 2550 **) | 0 | 60 | A |
| 278 | Ad3 Delay time of signal M5 at the start of the seam | ms | 2550 **) | 0 | 40 | A |
| 279 | At3 ON period of signal M5 at the start of the seam | ms | 2550 **) | 0 | 350 | A |
| 280 | kd1 Delay time | ms | 2550 **) | 0 | 0 *) | A |
| 281 | kt1 ON period | ms | 2550 **) | 0 | 100 *) | A |
| 282 | kd2 Delay time | ms | 2550 **) | 0 | 100 *) | A |
| 283 | kt2 ON period | ms | 2550 **) | 0 | 100 *) | A |
| 284 | kd3 Delay time | ms | 2550 **) | 0 | 200 *) | A |
| 285 | kt3 ON period | ms | 2550 **) | 0 | 100 *) | A |
| 286 | kd4 Delay time | ms | 2550 **) | 0 | 300 *) | A |
| 287 | kt4 ON period | ms | 2550 **) | 0 | 100 *) | A |
| 288 | kdF Delay time until sewing foot On | ms | 2550 **) | 0 | 380 *) | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

**) When programming the 3-digit or 4-digit control parameter values, the 2-digit or 3-digit value displayed must be multiplied by 10.

Supplier Level

Code no. 311 with control operation

| Parameter | Designation | Unit | max | min | Preset | Ind. |
|-----------|--|------|-----|-----|--------|------|
| 290 FAM | 0 = Lockstitch mode: (FA1, FA2, FA3, FA1+FA2); e. g. Brother Dürkopp Adler, Mitsubishi, Pfaff, Toyota 1 = Lockstitch mode: e. g. Singer (SN62AV) 2 = Lockstitch mode: e. g. Singer (212 UTT) 3...= Lockstitch mode: e. g. Dürkopp Adler (models 767, N291) 4 = Chainstitch mode: e. g. (US80A) 5 = Chainstitch mode in general: M1, M2, M3 and M4 parallel sequence 6 = Chainstitch mode with tape cutter and/or fast scissors and M1 / M2 at the seam end 7 = Overlock mode: e. g. (AC62AV1461) 8 = Backlatch mode: Pegasus 9 = Backlatch mode: Yamato 10 = Lockstitch mode: Union Special (63900AMZ »replacement for US80A«) and on Refrey lockstitch machines 13 = Lockstitch mode: Pfaff (1425) 14 = Lockstitch mode: Juki (5550-6, 5550-7) 15 = Function as in mode 0 16 = Function as in mode 0 17 = Chainstitch mode: Pegasus (stitch lock) 18 = Overlock mode: Bottoms 19 = Lockstitch mode: Macofrey 20 = Lockstitch mode: Juki (LU1510-7) 21 = Function as in mode 0 22 = Lockstitch mode: Brother (B-891) | | 22 | 0 | 5 | A |
| 297 | Functions of signal M3 0 = Function according to setting of parameter 290. 1 = Signal M3 is switched on whenever the light barrier is uncovered 2 = Signal M3 is switched on whenever the light barrier is covered 3 = Signal M3 is switched on only after light barrier uncovered and/or covered until seam end 4 = Signal M3 is switched on as with setting 3. Signal M5 (machine running), however, is switched off while signal M3 is issued. | | 4 | 0 | 0 *) | A |

*) Depending on the selected mode. See table at the beginning of the List of Parameters!

7 Error Displays

| General Information | |
|----------------------------|--|
| On the control | Signification |
| A1 | Pedal not in neutral position, when turning the machine on (according to setting of parameter 233) |
| A2 | Machine run blockage |
| A6 | Light barrier monitoring |
| A7 | Bobbin thread monitor |

| Programming Functions and Values (Parameters) | |
|--|---------------------------------------|
| On the control | Signification |
| Returns to 1st digit | Wrong code number or parameter number |

| Serious Condition | |
|--------------------------|--|
| On the control | Signification |
| E1 | After power On, position transmitter or commutation transmitter defective, or connecting cables have been changed by mistake. During operation or after a sewing cycle, only position transmitter defects can be identified. |
| E2 | Line voltage too low, or time between power off and power on too short. |
| E3 | Machine blocked or does not reach the desired speed. |
| E4 | Control disturbed by deficient grounding or loose contact. |

| Hardware Disturbance | |
|-----------------------------|--|
| On the control | Signification |
| H1 | Commutation transmitter cord or frequency converter disturbed. |
| H2 | Processor disturbed |



FRANKL & KIRCHNER GMBH & CO KG
SCHEFFELSTRASSE 73 – 68723 SCHWETZINGEN
TEL.: +49-6202-2020 – TELEFAX: +49-6202-202115
email: info@efka.net – <http://www.efka.net>



OF AMERICA INC.
3715 NORTHCREST ROAD – SUITE 10 – ATLANTA – GEORGIA 30340
PHONE: (770) 457-7006 – TELEFAX: (770) 458-3899 – email: efkaus@bellsouth.net



ELECTRONIC MOTORS SINGAPORE PTE. LTD.
67, AYER RAJAH CRESCENT 05-03 – SINGAPORE 139950
PHONE: +65-67772459 – TELEFAX: +65-67771048 – email: efkaems@efka.net